



More than products. Partnership.

MINI

Walk-behind spreader for spreading on narrow roads

MINI is a simple walk-behind spreader with a fixed spreading width designed for mounting on small tractors or utility vehicles.



✓ Simplicity of use

The MINI walk-behind spreader is easily mounted on small vehicles or tractors equipped with a towing hitch. It includes a dry agent hopper with a volume of 0.5 m³, and the spreading width is fixed at 1 meter.

✓ Power and control

MINI is powered by a switch-on mechanism on the spreader's wheels. The spreading material is taken from the tank using a roller with thrust plates, while the control of quantity of the used spreading material is performed by a mechanical lever for dosing.

✓ For narrow roads

Due to its smaller size, MINI is primarily designed for spreading on narrow roads such as sidewalks and bike paths, squares, edges of city parks, and other urban areas which larger spreaders have difficulties navigating or are not allowed to enter.



BASIC PARTS OF THE MINI SPREADER



1 | Control

The material is taken from the tank using a roller with thrust plates, while the control of quantity of the used spreading material is performed by a mechanical lever for dosing.

2 | Power

MINI is powered by a mechanism on the spreader's wheels.

3 | Mounting

MINI is mounted on vehicles equipped with a towing hitch (smaller tractors, utility vehicles)

4 | Traffic signalisation

Installed according to legal regulations in force in the country of use. Reflective labels and illuminated signs ensure good visibility of the spreader and vehicle in all weather conditions.

5 | Surface protection

Includes a combination of three systems (SurfaceArmour, hot-dip galvanizing, anti-corrosion wax application), depending on the part of the spreader in need of protection. It secures a long lifespan of the spreader even in the most difficult working conditions.

6 | Storage outside the season

Storage of spreaders outside the season is made easier with the use of storage legs.

TECHNICAL CHARACTERISTICS

Tank volume	Total device width	Spreading width
m ³	mm	
0.5	1360	1000

CHOICE OF SPREADER EQUIPMENT

- Protective screen for the hopper
- Cover tarpaulin
- Wheels with pneumatic tyres
- Wheels with air-filled tyres



RASCO d.o.o.
Kolodvorska 120b
HR - 48361 Kalinovac
Croatia



+385 48 883 112



rasco@rasco.hr



RascoCompany



Rasco_company



RascoTV



RASCO d.o.o.